




M20

Quectel Cellular Engine

EVB User Guide

M20_EVB_UGD_V1.02



Document Title	M20 EVB User Guide
Version	1.02
Date	2009-11-12
Status	Release
Document Control ID	M20_EVB_UGD_V1.02

General Notes

Quectel offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Quectel. The information provided is based upon requirements specifically provided for Quectel by the customers. Quectel has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Quectel within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Quectel Limited, copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Quectel Wireless Solutions Co., Ltd. 2009

Contents

0. Revision history	5
1. Introduction.....	6
1.1. Related documents	6
1.2. Safety caution	6
2. EVB kit introduction.....	8
2.1. EVB top and bottom view	8
2.2. EVB accessory	10
3. Interface application.....	11
3.1. Power interface.....	11
3.2. Audio interface.....	12
3.3. SIM card interface.....	13
3.4. Antenna interface	14
3.5. Serial ports	15
3.6. Switches and buttons.....	16
3.7. Operating status LED.....	17
3.8. Test points	18
3.8.1 J1 test points.....	19
3.8.2 J2 test points.....	20
3.8.3 J3 test points.....	21
3.8.4 VDD_EXT and VBAT test points	22
4. EVB assembly.....	23
5. Illustration	24
5.1. Power on operations.....	24
5.2. Communicate with the module.....	24
5.3. Firmware upgrade	24
5.4. Turn off.....	25
5.5. Emergency off.....	25
6. 50 PIN assignment of B2B connector	26

Table Index

TABLE 1: RELATED DOCUMENTS	6
TABLE 2: PIN OF POWER INTERFACE	11
TABLE 3: PINS OF AUDIO CHANNEL 1	12
TABLE 4: PINS OF AUDIO CHANNEL 2	12
TABLE 5: PINS OF SIM CARD INTERFACE	13
TABLE 6: PINS OF SERIAL PORT 0	15
TABLE 7: PINS OF SERIAL PORT 1	15
TABLE 8: SWITCHES AND BUTTONS	16
TABLE 9: OPERATING STATUS INDICATION LED	17
TABLE 10: PINS OF J1	19
TABLE 11: PINS OF J2	20
TABLE 12: PINS OF J3	21
TABLE 13: PIN DEFINITION OF B2B CONNECTOR	26

Figure Index

FIGURE 1: EVB TOP VIEW	8
FIGURE 2: EVB BOTTOM VIEW.....	9
FIGURE 3: ACCESSORY INTRODUCTION.....	10
FIGURE 4: POWER INTERFACE.....	11
FIGURE 5: AUDIO INTERFACE	12
FIGURE 6: SIM CARD INTERFACE.....	13
FIGURE 7: RF INTERFACE.....	14
FIGURE 8: ANTENNA INSTALLATION.....	14
FIGURE 9: SERIAL PORT 0& SERIAL PORT 1	15
FIGURE 10: SWITCHES AND BUTTONS.....	16
FIGURE 11: OPERATING STATUS INDICATION LED.....	17
FIGURE 12: TEST POINTS OVERVIEW	18
FIGURE 13: J1 TEST POINTS.....	19
FIGURE 14: J2 TEST POINTS.....	20
FIGURE 15: J3 TEST POINTS.....	21
FIGURE 16: VDD_EXT AND VBAT TEST POINTS	22
FIGURE 17: ASSEMBLED EVB AND ACCESSORIES.....	23
FIGURE 18: BOLTS TO SUPPORT EVB.....	23
FIGURE 19: SWITCHES STATE FOR FIRMWARE UPGRADE.....	25
FIGURE 20: B2B CONNECTOR OF EVB.....	26

0. Revision history

Revision	Date	Author	Description of change
1.00	2009-09-05	Tracy ZHANG	Initial
1.01	2009-09-29	Tracy ZHANG	Modified chapter number and title of Chapter 6
1.02	2009-11-12	Yong AN	The baud rate of the module is set to autobauding.

1. Introduction

This document defines and specifies the usage of M20 EVB.

1.1. Related documents

Table 1: Related documents

SN	Document name	Remark
[1]	M20_ATC	AT commands set
[2]	GSM_UART_AN	GSM UART port application notes
[3]	M20_HD	Hardware design
[4]	Upgrade_FW_Tools_UGD	User guide of firmware upgrade tools

1.2. Safety caution

The following safety precautions must be observed during all phases of the operation, such as usage, service or repair of any cellular terminal or mobile incorporating M20 module. Manufactures of the cellular terminal should send the following safety information to users and operating personnel and to incorporate these guidelines into all manuals supplied with the product. If not so, Quectel does not take on any liability for customer failure to comply with these precautions.



When in a hospital or other health care facility, observe the restrictions about the use of mobile. Switch the cellular terminal or mobile off. Medical equipment may be sensitive to not operate normally for RF energy interference.



Switch off the cellular terminal or mobile before boarding an aircraft. Make sure it switched off. The operation of wireless appliances in an aircraft is forbidden to prevent interference with communication systems. Forget to think much of these instructions may lead to the flight safety or offend against local legal action, or both.



Do not operate the cellular terminal or mobile in the presence of flammable gas or fume. Switch off the cellular terminal when you are near petrol station, fuel depot, chemical plant or where blasting operations are in progress. Operation of any electrical equipment in potentially explosive atmosphere can constitute a safety hazard.



Your cellular terminal or mobile receives and transmits radio frequency energy while switched on. RF interference can occur if it is used close to TV set, radio, computer or other electric equipment.



Road safety comes first! Do not use a hand-held cellular terminal or mobile while driving a vehicle, unless it is securely mounted in a holder for hands-free operation. Before making a call with a hand-held terminal or mobile, park the vehicle.



GSM cellular terminals or mobiles operate over radio frequency signal and cellular network and cannot be guaranteed to connect in all conditions, for example no mobile fee or an invalid SIM card. While you are in this condition and need emergent help, Please Remember using emergency call. In order to make or receive call, the cellular terminal or mobile must be switched on and in a service area with adequate cellular signal strength.

Some networks do not allow for emergency call if certain network services or phone features are in use (e.g. lock functions, fixed dialing etc.). You may have to deactivate those features before you can make an emergency call.

Also, some networks require that a valid SIM card be properly inserted in cellular terminal or mobile.

2. EVB kit introduction

2.1. EVB top and bottom view




Figure 1: EVB top view




Figure 2: EVB bottom view

- A: Serial port 1
- B: Serial port 0
- C: Test points
- D: SIM card socket
- E: Power adapter interface
- F: Module operating status indication LEDs
- G: PWRKEY button
- H: EMERG_OFF button
- I: 5V switch
- J: VCHG switch
- K: Download switch
- L: Screw holes for fixing the M20 module
- M: Headset socket
- N: Handset socket of audio channel 2
- O: Handset socket of audio channel 1
- P: Antenna connector fixing hole
- Q: Screw holes for EVB placement
- R: Connector for M20 module

2.2. EVB accessory




Figure 3: Accessory introduction

- A: 5V DC switching adapter
- B: USB to UART converter cable
- C: Quad-band GSM antenna
- D: RF cable
- E: Headset
- F: Bolts and nuts for fixing module in EVB

3. Interface application

3.1. Power interface




Figure 4: Power interface

Table 2: Pin of power interface

Pin	Signal	I/O	Description
1	Adapter input	I	5V/2A DC source input

The inner pin of the connector of power supply is positive. Customer should use the adapter which is provided by Quectel for testing M20 module.

3.2. Audio interface




Figure 5: Audio interface

Table 3: Pins of audio channel 1

Pin	Signal	I/O	Description
1	MIC1N	I	Negative microphone input
2	SPK1N	O	Negative receiver output
3	SPK1P	O	Positive receiver output
4	MIC1P	I	Positive microphone input

Table 4: Pins of audio channel 2

Pin	Signal	I/O	Description
1	MIC2N	I	Negative microphone input
2	AGND		AGND of audio circuits
3	SPK2P	O	Positive receiver output
4	MIC2P	I	Positive microphone input

A headset or handset can be used in audio channel 2. The headset is included in the EVB kit from Quectel, while a suitable desktop phone handset can be selected by customer according to the definition of signal in Table 4.

3.3. SIM card interface




Figure 6: SIM card interface

Table 5: Pins of SIM card interface

Pin	Signal	I/O	Description
1	SIM_GND		Ground
2	VPP		Not connected
3	SIM_DATA	I/O	SIM card data I/O
4	SIM_CLK	O	SIM card clock
5	SIM_RST	O	SIM card reset
6	SIM_VDD	O	SIM card power output
7	SIM_DETECT		Pulled up to VDD_EXT
8	SIM_PRESENCE	I	SIM card detection

In Figure 6, the pin SIM_PRESENCE is used to detect whether the tray of the Molex SIM socket, which is used for holding SIM card, is present in the card socket. When the tray is inserted in the socket, the pin 8 is connected to the pin7, so SIM_PRESENCE is at high level. For more details, please refer to *Document [3]*

3.4. Antenna interface




Figure 7: RF interface




Figure 8: Antenna installation

3.5. Serial ports




Figure 9: Serial port 0& Serial port 1

Table 6: Pins of Serial Port 0

Pin	Signal	I/O	Description
0_1	DCD0	O	Data carrier detection
0_2	TXD0	O	Transmit data
0_3	RXD0	I	Receive data
0_4	DTR0	I	Data terminal ready
0_5	GND		GND
0_7	RTS0	I	Request to send
0_8	CTS0	O	Clear to send
0_9	RI0	O	Ring indicator

The voltage level of these signals has been shifted to RS-232 level, so it can be directly connect to PC by USB to UART converter cable. This port is used for AT command, GPRS data, CSD FAX, multiplexing function and firmware upgrade.

Table 7: Pins of Serial Port 1

Pin	Signal	I/O	Description
1_2	TXD1	O	Transmit data
1_3	RXD1	I	Receive data
1_5	GND		GND

Customer can debug software through Serial Port 1, which is not for AT command, GPRS service, CSD call or FAX call.

3.6. Switches and buttons




Figure 10: Switches and buttons

Table 8: Switches and buttons

Part	Name	I/O	Description
S1	5V_SW	I	Control power supply from adaptor
S2	VCHG	I	Control charge to a Li-ion battery by the module.
S3	D/L	I	Place to ON when downloading firmware
K1	PWRKEY	I	Turn on/off the module
K2	EMERG_OFF	I	Shutdown the module in emergency. Hardware power off operation.

3.7. Operating status LED




Figure 11: Operating status indication LED

Table 9: Operating status indication LED

Part	Name	I/O	Description
L1	5V ON/OFF indicator	O	On: VBAT ON Off: VBAT OFF
L2	GSM_NET status indicator	O	Blinking differently to indicate various GSM network status

3.8. Test points




Figure 12: Test points overview

3.8.1 J1 test points



Figure 13: J1 test points

Table 10: Pins of J1

Pin	Signal	I/O	Description
1	VDD_EXT	O	Supply 2.8V voltage for external circuit
2	RXD1	I	Receive data of Serial Port 1
3	PWRKEY	I	Turn on/off the module
4	TXD1	O	Transmit data of Serial Port 1
5	EMERG_OFF	I	Shutdown the power in case of emergency
6	CTS1	O	Clear to send of Serial Port 1
7	VCHG	I	Voltage input for the charge circuit
8	RTS1	I	Request to send of Serial Port 1
9	VBAT	I	Power supply for module
10	GND		Digital ground

3.8.2 J2 test points




Figure 14: J2 test points

Table 11: Pins of J2

Pin	Signal	I/O	Description
1	DTR0	I	Data terminal ready of Serial Port 0
2	RXD0	I	Receive data of Serial Port 0
3	Reserve		
4	TXD0	O	Transmit data of Serial Port 0
5	RI0	O	Ring indicator of Serial Port 0
6	CTS0	O	Clear to send of Serial Port 0
7	GND		Digital ground
8	RTS0	I	Request to send of Serial Port 0
9	GND		Digital ground
10	DCDO	O	Data carrier detection of Serial Port 0

3.8.3 J3 test points




Figure 15: J3 test points

Table 12: Pins of J3

Pin	Signal	I/O	Description
1	RXDDAI	I	Receive digital audio data
2	SIM_PRESENCE	I	SIM card detection
3	TXDDAI	O	Transmit digital audio data
4	NETLIGHT	O	Network status indication
5	TFSDAI	O	Frame synchronization
6	Reserve		
7	SCLK	O	Serial bit clock
8	ADC1	I	ADC input
9	Reserve		
10	VRTC	I/O	Module RTC

3.8.4 VDD_EXT and VBAT test points




Figure 16: VDD_EXT and VBAT test points

Customer can test two test points to judge whether the power supply to the module or the VDD_EXT voltage from the module is correct or not.

4. EVB assembly

The EVB and its accessories are assembled as shown in Figure 17.



Figure 17: Assembled EVB and accessories



Figure 18: Bolts to support EVB

5. Illustration

5.1. Power on operations

- (1) Connect the M20 module to the 50-pin connector on the M20 EVB. Put Switch S1 to **ON** state. Put Switch S2 to **OFF** position and Switch S3 to **OFF** position. Plug in 5V DC adapter. The LED L1 on the EVB will be bright.
- (2) Press the PWRKEY button for more than 2 seconds, and the module will begin to run. The blinking mode of the LED L2 indicates the status of the module.

5.2. Communicate with the module

- (1) Connect the Serial Port 0 on EVB to PC's USB port with the USB to UART converter cable.
- (2) Open the HyperTerminal (AT command window) in the PC. The location of the HyperTerminal in windows XP is START →program →accessory →communication →HyperTerminal. Set appropriate Baud Rate (such as 115200 bps) and COM port number which can be checked by the Device Manager in the PC.
- (3) Connect an antenna to the M20 with an RF cable.
- (4) Insert SIM card into the SIM card socket.
- (5) Insert earphone or handset into audio interface.
- (6) Power on the module by pressing PWRKEY button.
- (7) After waiting for 2~3 seconds, customer should firstly input "AT" or "at" string once or more until receiving "OK" from the module in the HyperTerminal.
The module is set to autobauding mode in default configuration. This operation is to synchronize the baud rate between the computer and the module.
- (8) Input AT command and the module will execute its corresponding function.
Customer can refer to *Document [1]* for details of AT commands. For instance, typing "ATD112;" will make a call to the emergency number 112.

5.3. Firmware upgrade

- (1) Start the Firmware Upgrade Tool in the PC.
- (2) Press the **START** button in the Firmware Upgrade Tool.
- (3) Switch the S3 and S1 in the EVB to **ON** state as shown in Figure 19.
After these steps, the firmware refreshing process will be proceeding. For more details, please refer to *Document [4]*.




Figure 19: Switches state for firmware upgrade

5.4. Turn off

Pressing the PWRKEY button for about 1 second will turn off the module.

5.5. Emergency off

Pressing the EMERG_OFF button for more than 0.1 second will shutdown the module immediately. After this operation, the module can be restarted by pressing the PWRKEY button. Please note that the operation is harmful to the whole module system and should only be done in emergency such as failing to turn off the module through the PWRKEY button.

6. 50 PIN assignment of B2B connector




Figure 20: B2B connector of EVB

Table 13: Pin definition of B2B connector

PIN NO.	PIN NAME	I/O	PIN NO.	PIN NAME	I/O
1	SIM_CLK	O	50	AGND	
2	SIM_VDD	O	49	SPK2P	O
3	SIM_DATA	I/O	48	SPK1P	O
4	SIM_RST	O	47	SPK1N	O
5	SIM_PRESENCE	I	46	MIC2N	I
6	SIM_GND		45	MIC2P	I
7	RXDDAI	I	44	MIC1P	I
8	TFSDAI	O	43	MIC1N	I
9	SCLK	O	42	AGND	
10	TXDDAI	O	41	PWRKEY	I
11	Reserve	O	40	EMERG_OFF	I
12	ADC1	I	39	DCD0	O
13	NETLIGHT	I/O	38	CTS1	O
14	TXD1	O	37	CTS0	O

15	TXD0	O	36	RTS1	I
16	RXD1	I	35	DTR0	I
17	RXD0	I	34	RTS0	I
18	VRTC	I/O	33	Reserve	
19	VCHG	I	32	RI0	O
20	Reserve	O	31	VDD_EXT	O
21	GND		30	VBAT	I
22	GND		29	VBAT	I
23	GND		28	VBAT	I
24	GND		27	VBAT	I
25	GND		26	VBAT	I

QUECTEL



Shanghai Quectel Wireless Solutions Co., Ltd.

Room 801, Building E, No.1618, Yishan Road, Shanghai, China 201103

Tel: +86 21 5108 2965

Mail: info@quectel.com